



Grand Rental Station
 570 Rudder Rd
 Fenton, MO 63026
 P: 636-343-7278
 info@grandrental-stl.com
 www.grandrental-stl.com



Coffee Maker Instructions

Operating Instructions:

- 1) Fill maker to desired level with **COLD** water.
- 2) Add coffee according to manufacturer's recommendations or the chart listed below.
- 3) Plug coffee maker into proper electrical outlet.
- 4) Remove coffee grounds when coffee has finished brewing.

Coffee Equivalents:

| <u>Number of Cups</u> | <u>Coffee Measurements</u> |
|-----------------------|----------------------------|
| 30 | 2 Cups |
| 55-60 | 4 Cups |
| 90 | 6 Cups |

Brewing Time: (approximate)

| | |
|---------------|------------|
| 30 - 60 Cups | 60 minutes |
| 90 - 100 Cups | 90 minutes |

Note: One pound of coffee is equal to 4.75 cups of ground coffee.

Cleaning Instructions:

- 1) Rinse coffee maker before returning
- 2) NEVER IMMERSE COFFEE MAKER IN WATER

Consult Grand Rental Station for additional equipment and accessories for your special event.

UNDERSTAND YOUR RENTAL CONTRACT. KNOW YOUR RESPONSIBILITY FOR THE EQUIPMENT YOU HAVE RENTED



These guidelines and tips are common-sense suggestions designed to promote Coffee Maker efficiency and safety. Compiled from literature of leading experts in the field, they are believed to be reliable, and are offered as suggestions and illustrations to deal principally with common practices and conditions encountered in the use of Coffee Makers. The guidelines are not intended to be all-inclusive, complete descriptions of safe practices, or to supplant or replace other additional precautionary measures to cover usual or unusual conditions or situations where common-sense might otherwise dictate. Accordingly, the American Rental Association and its member firms disclaim all liability for, and make no warranty or guarantee of the accuracy or applicability of this information in any situation.