

Grand Rental Station


570 Rudder Rd Fenton, MO 63026 P: 636-343-7278 info@grandrental-stl.com www.grandrental-stl.com



Dance Floor Instructions


It is important that all debris and lumpy material be removed from the underlying surface before begining the installation process.

There are two parts to the interlocking dance floor system:




All modules should have the female loops going in the same direction (illustration 1). Place the pegs in the loops, matching the corners of the modules and simply step down. The lock will "snap" when it engages and the surface will appear smooth and even upon completion.

Caution: If you in advertently rotate a tile 90° it will snap into place (illustration 2), but you will not be able to complete the installation properly.



Always begin the installation in one corner, pointing loops in the direction the additional modules are to be added (illustration 3).



Consult Grand Rental Station for additional equipment and accessories for your special event.

UNDERSTAND YOUR RENTAL CONTRACT. KNOW YOUR RESPONSIBILITY FOR THE EQUIPMENT YOU HAVE RENTED

These guidelines and tips are common-sense suggestions designed to promote Dance Floor efficiency and safety. Compiled from literature of leading experts in the field, they are believed to be reliable, and are offered as suggestions and illustrations to deal principally with common practices and conditions encountered in the use of Dance Floor. The guidelines are not intended to be all-inclusive, complete descriptions of safe practices, or to supplant or replace other additional precautionary measures to cover usual or unusual conditions or situations where common-sense might otherwise dictate. Accordingly, the Grand Rental Station disclaims all liability for, and make no warranty or guarantee of the accuracy or applicability of this information in any situation.